

¿Dónde encontrar su PIN?

Para visualizar su número PIN haga click en la opción "Wireless-->WPS", ubicada en la interfaz de administración web.

The screenshot shows the web management interface of a "WIRELESS - N ROUTER IEEE 802.11N 2.0". The left sidebar contains a "Site contents" menu with the following items: Setup Wizard, Operation Mode, **Wireless**, Basic Settings, Advanced Settings, Security, Access Control, WDS settings, Site Survey, **WPS**, Schedule, TCP/IP, Firewall, QoS, Route Setup, Management, and Logout. A tooltip labeled "Wi-Fi Protected Setup" points to the "WPS" menu item. The main content area is titled "Wi-Fi Protected Setup" and contains the following text: "This page allows you to change the setting for WPS (Wi-Fi Protected Setup). Using this feature could let your wireless client automatically synchronize its setting and connect to the Access Point in a minute without any hassle." Below this text is a checkbox labeled "Disable WPS" which is currently unchecked. There are two buttons: "Apply Changes" and "Reset". The "WPS Status:" section shows "Configured" selected with a radio button, and "UnConfigured" with an unselected radio button. A "Reset to UnConfigured" button is present. The "Self-PIN Number:" is displayed as "73943334". The "Push Button Configuration:" section has a "Start PBC" button. The "Client PIN Number:" section has an empty input field and a "Start PIN" button.